





INSTALLATION INSTRUCTIONS
Polaris Ranger 400-500 Plastic Roof


Item	Description	Qty
A	Roof Half (Passenger)	1
B	Roof Half (Driver)	1
C	Tube Clamps	12



Qty (14)  M6-1.0 x 20mm Lg. PHMS

Qty (14)  M6-1.0 Nylock Nut

Qty (12)  M6 Fender Washer

Qty (4)  M6 Flat Washer

Read instructions and view illustrations before beginning.

Need help with your installation?

 sales@superatv.com  www.superatv.com

 1-812-574-7777  8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

*Thank You
 For Choosing*



Liability Statement

SuperATV's products are designed to best fit users ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory, or aftermarket, parts will void any warranty provided by SuperATV and is not recommended. SuperATV's products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV to verify that they will work together.

Although SuperATV has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV products, user agrees that should damages occur, SuperATV will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV will warranty only parts provided by SuperATV. Any damage or problems with OEM housings, bearings, seals, or other manufacturers products will not be covered by SuperATV. SuperATV parts and products are not warrantied if item was not installed properly, misused, or modified.

Do not tighten hardware completely unless noted.

1. Place Roof Half (B) on top of machine followed by Roof Half (A).
 2. Place (12) Tube Clamps (C) around Roll Bar. Attach Roof (A)(B) to Tube Clamps (C) using (12) each M6-1.0 x 20mm Lg. PHMS, M6 Fender Washers, and M6-1.0 Nylock Nuts. See Figs. 1 - 1c.
 3. Tighten hardware completely.
 4. Drill (2) $\text{Ø}1/4''$ holes through Roof Halfs (A)(B). See Fig. 2.
- Join with M6-1.0 x 20mm Lg. PHMS, M6 Flat Washers, and M6-1.0 Nylock Nuts. See Fig. 2.

